

# 프로젝트 생성



Application name: GpsTmap03

Company Domain: admid.example.com

Project location: C: □Android □StdWork □tampnewtest

**Target Android Devices** 

- Phone and Tablet

- Minimun SDK API 20

Add an activity to Mobile: Empty Activity

Customize the Activity

**Activity Name: MainActivity** 

Layout Name: activity\_main



6:00

gpstmap

```
activity_main.xml ×

ClinearLayout xmlns:android="http://schemas.android.com/apk/res/android"
    xmlns:tools="http://schemas.android.com/tools"
    android:layout_width="match_parent"
    android:layout_height="match_parent"
    android:id="@+id/linear"
    android:orientation="vertical"
    tools:context=".MainActivity">
```

```
MainActivity.java ×
       package com.example.administrator.gpstmap03;
 2
 3
       import android.graphics.Bitmap;
       import android.location.Location;
 4
 5
       import android.location.LocationListener;
 6
       import android.os.Bundle;
       import android.support.v7.app.AppCompatActivity;
 8
       import android.widget.LinearLayout;
 9
       import com.skp.Tmap.IMapCircle;
10
11
       import com.skp.Tmap.TMapData;
12
       import com.skp.Tmap.TMapGpsManager;
13
       import com.skp.Tmap.TMapMarkerItem;
14
       import com.skp.Tmap.TMapPOlltem;
15
       import com.skp.Tmap.TMapPoint;
16
       import com.skp.Tmap.TMapView;
17
       import java.util.ArravList;
18
19
```

## **MainActivity**

## **MainActivity**

```
MainActivity.java ×
19
20 💁
       public class MainActivity extends AppCompatActivity
21
               implements TMapView.OnLongClickListenerCallback,
22
              LocationListener. TMapGpsManager.onLocationChangedCallback {
23
24
          private IMapView tMapView = null;
25
           TMapGpsManager gps = null;
26
          public static String mApiKey = null;
27
28
          private static final String TAG = "TestImap";
29
           Bitmap icon1, icon2;
30.
           TMapCircle tCircle:
31
           TMapData tMapData:
32
           TMapPoint point2 = null;
33
```

```
MainActivity.java ×
34
           @Override
35 of 📥
           protected void onCreate(Bundle savedInstanceState) {
36
               super.onCreate(savedInstanceState);
37
               setContentView(R.layout.activity_main);
38
               LinearLayout liner = (LinearLayout) findViewByld(R.id.linear);
39
40
               tMapView = new IMapView(this);
41
               mApiKey = "3fbf4752-cf6c-318b-c
                                                              38c79":
42
               tMapView.setSKPMapApiKey(mApiKey);
43
44
               liner.addView(tMapView);
45
               setContentView(Liner):
46
47
               gps = new TMapGpsManager(MainActivity.this);
48
               gps.setMinTime(1);
               gps.setMinDistance(1);
49
               gps.setProvider(gps.NETWORK_PROVIDER);
50
51
               // gps.setProvider(gps.GPS_PROVIDER);
52
               gps.OpenGps();
53
```


```
MainActivity.java ×
53
54
               tMapData = new TMapData();
55
56
               tMapView.setZoomLevel(16);
57
               tMapView.setIconVisibility(true):
58
               tMapView.setCompassMode(true);
59
               tMapView.setSightVisible(true):
60
               tMapView.setMapPosition(TMapView.POSITION_NAVI);
61
               tMapView.setTrackingMode(true);
62
63
64
```

```
    MainActivity.java ×

64
65
           @Override
           public void onLocationChanged(Location location) {
66 of
67
68
69
70
           @Override
           public void onStatusChanged(String provider, int status, Bundle extras) {
72
73
74
75
           @Override
76 of
           public void onProviderEnabled(String provider) {
77
78
79
80
           @Override
           public void onProviderDisabled(String provider) {
83
84
85
           @Override
86 🜒
           public void onLongPressEvent(ArrayList<TMapMarkerItem> arrayList.
87
                                         ArrayList<TMapPOlltem> arrayList1, TMapPoint tMapPoint) {
88
90
```

```
MainActivity.java ×
 ಶ೨
84
85
            @Override
86 🜒
            public void onLongPressEvent(ArrayList<TMapMarkerItem> arrayList.
87
                                         ArrayList<TMapPOlltem> arrayList1, TMapPoint tMapPoint) {
 88
89
90
91
            @Override
92 🜒
            public void onLocationChange(Location location) {
93
                tMapView.setCenterPoint(location.getLongitude(), location.getLatitude());
94
                tMapView.setLocationPoint(location.getLongitude(), location.getLatitude());
95
96
97
            @Override
98 📬
            protected void onDestrov() {
99
                super.onDestroy();
100
                gps.CloseGps();
101
102
103
            @Override
            protected void onPause() { super.onPause(); }
104 💿 🖨
107
```

```
<?xml version="1.0" encoding="utf-8"?>
manifest xmlns:android="http://schemas.android.com/apk/res/android"
   package="com.example.administrator.gpstmap03">
   quses-permission android:name="android.permission.INTERNET" />
   <uses-permission android:name="android.permission.ACCESS_NETWORK_STATE" />
   <uses-permission android:name="android.permission.WRITE_OWNER_DATA" />
   <uses-permission android:name="android.permission.READ_OWNER_DATA" />
   quses-permission android:name="android.permission.ACCESS_FINE_LOCATION" />
   <application
       android:allowBackup="true"
       android:icon="@mipmap/ic_launcher"
      android: label = "GosTmap03"
      android:theme="@style/AppTheme">
       <act ivity
          android:name=".MainActivity"
          android: label="GpsTmap03">
          <intent-filter>
              <action android:name="android.intent.action.MAIN" />
              <category android:name="android.intent.category.LAUNCHER" />
          </intent-filter>
       </activity>
   </application>
</manifest>
```




### 마커 찍기


```
MainActivity.java ×
               gps. Secritions cance(1)/
43
               gps.setProvider(gps.NETWORK_PROVIDER);
50
51
               // gps.setProvider(gps.GPS_PROVIDER);
52
               gps.OpenGps();
53
54
               tMapData = new IMapData();
55
56
               tMapView.setZoomLevel(16):
57
              // tMapView.setIconVisibility(true);
58
               tMapView.setCompassMode(true);
59
               tMapView.setSightVisible(true):
60
               tMapView.setMapPosition(TMapView.POSITION_NAVI);
61
               tMapView.setTrackingMode(true);
62
63
```

```
    MainActivity.java ×

04
85
86
87
           @Override
88 🖈
           public void onLongPressEvent(ArravList<TMapMarkerItem> arravList.
89
                                         ArrayList<TMapPOIItem> arrayList1, TMapPoint tMapPoint) {
               tMapView.setIconVisibility(false);
90
               Bitmap bitmap = BitmapFactory. decodeResource(getResources(), R.drawable.icon3);
91
92
93
               Toast.makeText(getBaseContext(), String.valueOf(tMapPoint.getLatitude()) + ", "
                       + String.valueOf(tMapPoint.getLongitude()), Toast.LENGTH_SHORT).show();
94
95
               tNapView.setIcon(bitmap);
96
               tMapView.setIconVisibility(true):
97
```









15

임의의 맵 롱 클릭



111




```
 MainActivity.java ×

18
       import com.skp.Tmap.TMapView;
19
20
       import java.util.ArrayList;
21
22 🔯
       public class MainActivity extends AppCompatActivity
               implements TMapView.OnLongClickListenerCallback,
23
24
               LocationListener, TMapGpsManager.onLocationChangedCallback,
               TMapView.OnCalloutRightButtonClickCallback{
25
26
27
           private TMapView tMapView = null;
28
           TMapGpsManager gps = null;
```


```
    MainActivity.java ×

            @Override
130
131 💿 📥
           protected void onPause() {
               super.onPause();
132
133
134
135
            @Override
136 🗊 占
           public void onCalloutRightButton(TMapMarkerItem tMapMarkerItem) {
137
                Toast.makeText(getApplicationContext(), "클릭했네요", Toast.LENGTH_SHORT).show();
138
139
140
```



#### 여러 개의 마커 중에서 이벤트 주기

```
MainActivity.java ×
130
           @Override
131 💿 📥
           protected void onPause() {
132
                super.onPause();
133
134
135
            @Override
136 🜒 占
           public void onCalloutRightButton(TMapMarkerItem tMapMarkerItem) {
137
                if(tMapMarkerItem.getID() == "ID_01") {
138
                    Toast.makeText(getApplicationContext(), "ID_01 클릭했네요",
139
140
                            Toast.LENGTH_SHORT).show();
141
142
143
       }
144
```





### 두 번째 마커 찍기

```
MainActivity.java ×
24
               LocationListener, TMapGpsManager.onLocationChangedCallback,
25
               TMapView.OnCalloutRightButtonClickCallback{
26
27
           private IMapView tMapView = null;
28
           TMapGpsManager gps = null;
29
           public static String mApiKey = null;
30
           private static final String TAG = "TestImap";
31
32
           Bitmap icon1, icon2;
33
           TMapCircle tCircle;
34
           TMapData tMapData:
35
           TMapPoint point2 = null;
           TMapMarkerItem item1 = new TMapMarkerItem();
36
37
           TMapMarkerItem item2 = new TMapMarkerItem();
38
39
           @Override
           protected void onCreate(Bundle savedInstanceState) {
40 of
```

```
MainActivity.java ×
 98
                  tMapView.setIconVisibility(true);
 99
                TMapPoint point1 = new TMapPoint(tMapPoint.getLatitude(), tMapPoint.getLongitude());
100
                TMapPoint point2 = new TMapPoint(tMapPoint.getLatitude()+0.01, tMapPoint.getLongitude());
101
102
               // TMapMarkerItem item1 = new TMapMarkerItem();
103
                Bitmap bitmap3 = BitmapFactory.decodeResource(getResources(), R.drawable.icon3);
104
                Bitmap bitmap5 = BitmapFactory.decodeResource(getResources(), R.drawable.icon5);
105
                item1.setTMapPoint(point1);
                item1.setName("Target");
106
107
                item1.setVisible(item1.VISIBLE);
108
                item1.set[con(bitmap3);
109
110
                item1.setCalloutTitle("넘버1");
111
                item1.setCalloutSubTitle("위치 추적");
112
                item1.setCanShowCallout(true);
113
                item1.setAutoCalloutVisible(true);
```

```
MainActivity.java ×
114
115
                item2.setTMapPoint(point2);
116
                item2.setName("Target");
117
                item2.setVisible(item2.VISIBLE);
118
                item2.set[con(bitmap5);
119
                item2.setCalloutTitle("넘버2");
120
121
                item2.setCalloutSubTitle("위치 추적");
122
                item2.setCanShowCallout(true);
123
                item2.setAutoCalloutVisible(true);
124
125
126
                Bitmap bitmap_i = BitmapFactory.decodeResource(getResources(), R.drawable.icon4);
127
                item1.setCalloutRightButtonImage(bitmap_i);
128
                tMapView.addMarkerItem("ID_01", item1);
129
                tMapView.addMarkerItem("ID_02", item2);
130
131
```






2. 맵 축소

## 폴리 라인


```
MainActivity.java ×
          TMapCircle tCircle:
35
36
          JMapData_tMapData:
37
          TMapPoint point1 = null:
          TMapPoint point2 = null;
38
          39
          TMapMarkerItem item2 = new TMapMarkerItem();
40
41
          TMapPolyLine tpolyline = new TMapPolyLine();
42
43
          @Override
44 of
         protected void onCreate(Bundle savedInstanceState) {
             super.onCreate(savedInstanceState);
45
46
             setContentView(R.layout.activity_main);
```

```
MainActivity.java ×
134
135
            @Override
136
137 of
            public void onLocationChange(Location location) {
138
                tMapView.setCenterPoint(location.getLongitude(), location.getLatitude());
                tNapView.setLocationPoint(location.getLongitude(), location.getLatitude());
139
140
141
                point1 = new TMapPoint(location.getLatitude(), location.getLongitude());
142
                point2 = new TMapPoint(location.getLatitude()+0.01, location.getLongitude());
143
144
                tpolvline.setLineColor(Color.BLUE);
145
                tpolyline.setLineWidth(2);
146
                tpolyline.addLinePoint(point1);
147
                tpolyline.addLinePoint(point2);
148
                tMapView.addTMapPolyLine("tpO1", tpolyline);
149
```



## 폴리라인 거리 구하기

```
MainActivity.java ×
143
144
                tMapView.removeAllTMapPolyLine();
145
                tpolyline.setLineColor(Color.BLUE);
146
                tpolyline.setLineWidth(2):
147
                tpolyline.addLinePoint(point1);
                tpolyline.addLinePoint(point2);
148
149
                tMapView.addTMapPolyLine("tpO1", tpolyline);
150
151
                double Distance = tpolyline.getDistance();
152
                Toast.makeText(getApplicationContext(), String.valueOf(Distance),
153
                        Toast.LENGTH_SHORT).show();
154
155
```



```
MainActivity.java ×
36
           TMapCircle tCircle;
37
           TMapData tMapData:
38
           TMapPoint point1 = null;
39
           TMapPoint point2 = null;
4Ω
           IMapPoint point3 = null;
41
           TMapPoint point4 = null;
42
           TMapMarkerItem item1 = new TMapMarkerItem();
43
           TMapMarkerItem item2 = new TMapMarkerItem();
44
           TMapPolyLine tpolyline = new TMapPolyLine();
           TMapPolygon tpolygon = new TMapPolygon();
45
46
47
           @Override
48 of
           protected void onCreate(Bundle savedInstanceState) {
49
               super.onCreate(savedInstanceState);
```

```
MainActivity.java ×
139
140
            @Override
141 of
            public void onLocationChange(Location location) {
142
                tMapView.setCenterPoint(location.getLongitude(), location.getLatitude());
143
                tMapView.setLocationPoint(location.getLongitude(), location.getLatitude());
144
145
                point1 = new TMapPoint(location.getLatitude(), location.getLongitude());
146
                point2 = new TMapPoint(location.getLatitude()+0.01, location.getLongitude());
                point3 = new TMapPoint(location.getLatitude()+0.01. location.getLongitude()+0.01);
147
                point4 = new TMapPoint(location.getLatitude(), location.getLongitude()+0.01);
148
149
150
                tMapView.removeAllTMapPolyLine();
151
                tpolvline.setLineColor(Color.BLUE);
```

```
MainActivity.java ×
               double Distance = tpolyline.getDistance();
157
158
                Toast.makeText(getApplicationContext(), String.valueOf(Distance),
159
                        Toast.LENGTH_SHORT).show();
160
161
                tpolygon.setLineColor(Color.RED): //플리곤 선색
162
                tpolygon.setPolygonWidth(2);
                tpolygon.setAreaColor(Color.BLUE);
163
164
                tpolygon.setAreaAlpha(20);
165
                tpolygon.setLineAlpha(20);
166
                tpolygon.addPolygonPoint(point1);
167
                tpolygon.addPolygonPoint(point2);
168
                tpolygon.addPolygonPoint(point3);
169
                tpolygon.addPolygonPoint(point4);
                tMapView.addTMapPolygon("pollD", tpolygon);
170
171
172
```

